Dispenser Operation Guide



KANPAK - VERSION 2.2



perforated opening

cap

thumb screw

General Instructions

- Product must be chilled to between 34 °F and 41 °F before loading into the dispenser.
- It is normal for ice to form on the interior of the dispenser compartment.
- The cleaning schedule must be followed to maintain sanitary operation.

Product Storage Instructions

- The product may be stored at ambient or chilled temperature before opening but must be chilled after opening.
- The product must be chilled to between 34 °F and 41 °F or before loading in the dispenser.
- To chill the product, place in a cooler for at least 24 hours.

Product Loading Instructions

- 1. Sanitize your hands or wear gloves before loading the product.
- 2. Confirm the product is chilled to between 34 °F and 41 °F.
- 3. Punch out the perforated opening on the edge of the case box.
- 4. Locate the cap with a tube and move the cap toward the perforated opening.
- 5. Pull the tube through the perforated opening and remove the tube from the locking feature in the cap.
- 6. Load the case into the dispenser. Confirm the variety label matches the variety shown on the dispenser graphic.
- 7. Remove the clear plastic film covering the tube.
- 8. Loosen the thumbscrew and open the valve door.
- 9. Center the tube in the valve. Ensure the tube is not kinked or twisted.
- 10. Close the valve door and tighten the thumbscrew.
- 11. Cut the tube with clean, sharp scissors ½ inch below the valve at a 45 degree angle.

UPROOT INC. DISPENSERS@UPROOTMILK.COM (401) 216-7172

Dispenser Operation Guide



KANPAK - VERSION 2.2

Troubleshooting

PRODUCT IS LEAKING FROM THE TUBE

- Make sure the valve door is completely closed and the thumbscrew is tight.
- Make sure the dispensing tube is aligned in the center of the valve.
- Make sure the valve assembly is not damaged.
- Make sure the product is not frozen in the bag or at the valve.

DISPENSER CABINET IS TOO WARM

- Make sure the product is chilled to between 34 °F and 41 °F before loading it into the dispenser.
- Make sure the dispenser is not close to a heat-generating source, such as a coffee maker, heat lamp or direct sunlight.
- Make sure there is at least 1 inch of space on all sides of the dispenser.
- Make sure the vents at the back of the dispenser are not blocked.

ICE IS BUILDING UP INSIDE THE DISPENSER

- Make sure the door is properly sealed and that the door gasket is intact.
- Make sure to wipe away condensation inside the dispenser when loading product.
- Ice build up is normal. Follow instructions for cleaning the product compartment to remove ice.

PRODUCT IS FREEZING IN THE PACKAGING

- Make sure that a product ramp is installed in the dispenser.
- Make sure the product is chilled to between 34 °F and 41 °F before loading it into the dispenser.

PRODUCT IS DISPENSING SLOWLY

- Make sure the dispensing tube is not bent or twisted.
- Make sure that the product is not frozen in the bag or at the valve.

Manufacturer Support

1 (800) 569-0826 KPSERVICE@KANPAK.US

UPROOT INC. DISPENSERS@UPROOTMILK.COM (401) 216-7172