

Dispenser Quickstart Guide

KANPAK - VERSION 1.0



Preparation

1. Refrigerate the Uproot product. It must be chilled to 41°F or below before loading into the dispenser.
2. Locate the dispenser installation location.
 - i. There must be a standard power outlet within 5 feet of the installation location.
 - ii. There must be 22 inches of available counter width at the installation location. The dispenser is 16 inches wide and requires 3 inches of clearance on each side.
3. Inspect the dispenser box and document any damage.
4. Remove the dispenser box from the pallet.

Dispenser Installation

1. Place the dispenser box in a suitable location for unboxing near the installation location.
2. Cut the plastic straps with a blade or scissors.
3. Preserve the packaging until the dispenser has started correctly.
4. Lift the top off of the dispenser box.
5. Remove the packing material from the top and sides of the dispenser.
6. Lift the sides and protective bag off the dispenser.
7. Remove the gray protective plastic film from top and rear of the dispenser.
8. Remove the drip tray and ramp from the dispenser cabinet and set aside.
9. With one person on each side, lift the dispenser onto a rolling cart or to the installation location. Place a foot on the foam under the dispenser to remove it as you lift. Place the dispenser at the installation location.
10. Remove the protective plastic film from the drip tray and product ramp. Place the drip tray on the two screwheads on the front of the dispenser and place the product ramp in the product cabinet.
11. Remove the protective plastic from the thermometer on the interior of the dispenser door. Place the thermometer on the metal plate on the interior of the door.
12. Plug in the dispenser and turn on the power switch on the left side.
13. Confirm that the "POWER" light on the front of the dispenser and the backlit display are illuminated.
14. Wait 2 hours for the dispenser to chill.
15. Confirm that the "READY" light is illuminated and the thermometer reads 41°F or below.